

Equipment Utilization Chart

The following Lab-Volt equipment is required to perform the exercises in this manual.

EQUIPMENT		EXERCISE							
MODEL	DESCRIPTION	1-1	1-2	1-3	1-4	1-5	1-6	2-1	2-2
3103-3	Mobile Workstation	1	1	1	1	1	1	1	1
3112	Switches					2	2		
3114	Emergency Button					1	1		
3115-A	Pilot Lights				1		1		
3125-1	Lockout Module	1	1	1	1	1	1	1	1
3126	Manual Starter				1			1	
3130-2	Control Relay					1			
3138-3	Control Transformer					1			
3140-3	Cam Switch								1
3147-1	Inertia Wheel		1	1		1			
3150-1	Starting Resistors				1				1
3165-1	Power Diodes								1
3176-A	Brake Motor	1	1	1	1	1	1		1
3179-2	DC Motor			1	1			1	1
3183	AC Drive	1	1	1	1	1	1		
3184	DC Drive		1	1				1	1
3196	AC Power Supply	1	1	1	1	1	1	1	1
8951-8	Connection Leads	1	1	1	1	1	1	1	1
8951-E	Connection Leads		1	1	1	1	1	1	1
38503	Magnetic Labels		1	1	1	1	1	1	1
Option	Multimeter ¹		1	1				1	1
Option	Chronometer			1					
Option	Tachometer		1					1	1

¹ Voltmeter and DC ammeter

Diagram Symbols




Figure B-1. NEMA symbols.

FUNCTION OR DEVICE	DESIGNATION	FUNCTION OR DEVICE	DESIGNATION
Accelerating	A	Overload	OL
Ammeter	AM	Overvoltage	OV
Braking	B	Plugging or Potentiometer	P
Capacitor, Capacitance	C or CAP	Power Factor Meter	PFM
Circuit Breaker	CB	Pressure Switch	PS
Closing Coil	CC	Push Button	PB
Control Relay	CR	Reactor, Reactance	X
Current Transformer	CT	Rectifier	REC
Demand Meter	DM	Resistor, Resistance	R or RES
Diode	D	Reverse	R or REV
Disconnect Switch	DS or DISC	Rheostat	RH
Dynamic Braking	DB	Selector Switch	SS
Field Accelerating	FA	Silicon Controlled Rectifier	SCR
Field Contactor	FC	Solenoid Valve	SV
Field Decelerating	FD	Squirrel Cage	SC
Field-Loss	FL	Starting Contactor	S
Forward	F or FWD	Suppressor	SU
Frequency Meter	FM	Tachometer Generator	TACH
Fuse	FU	Terminal Block or Board	TB
Ground Protective	GP	Time-Delay Closing Contact	TC or TDC
Holding Coil	HC	Time-Delay Opening Contact	TO or TDO
Hoist	H	Time Relay	TR
Jog	J	Transformer	T
Latch Coil	LC	Transistor	Q
Limit Switch	LS	Trip Coil	TC
Lower	L	Unlatch Coil	ULC
Main Contactor	M	Undervoltage	UV
Master Control Relay	MCR	Voltmeter	VM
Master Switch	MS	Watt-hour Meter	WHM
Overcurrent	OC	Wattmeter	WM

Figure B-2. Device designations.

























	NEMA	IEC
MAGNETIC OVERLOAD ELEMENT (SHORT-CIRCUIT)		
THERMAL OVERLOAD ELEMENT		
RELAY COIL		
NORMALLY OPEN CONTACT		
NORMALLY CLOSED CONTACT		
TRANSFER CONTACTS		
NORMALLY OPEN CONTACT DELAYED WHEN CLOSING		
NORMALLY OPEN CONTACT (LIMIT SWITCH)		
NORMALLY OPEN PUSHBUTTON CONTACT		
CONTACTOR		
THREE-POLE SWITCH-DISCONNECTOR		
THREE-POLE CIRCUIT-BREAKER WITH THERMAL OVERLOAD RELEASES		

Figure B-3. Comparison of NEMA and IEC symbols.

Basic Setup and Lockout/Tagout Procedures

This appendix contains the Basic Setup and Lockout/Tagout procedures specific to the Industrial Controls Training System from Lab-Volt. It is divided into four sections:

- Basic Setup procedure, explains the basic operations that must be performed at the beginning of the exercise procedures.
- Lockout/Tagout procedure (de-energizing procedure), describes the lockout/tagout procedure used to de-energize the training system before setting up a circuit.
- Energizing procedure, gives details on how to end a lockout/tagout procedure and energize the training system.
- Module identification, gives instructions on how to use the magnetic labels to identify the modules.

Basic Setup procedure

This procedure is recommended at the beginning of every experiment involving the modules of the training system. It ensures that the system is safe prior to cabling specific circuits.

Figure C-1 shows the AC Power Supply, Model 3196. Individual power switches are located on both faces of the module, for separate control of the power source.



Figure C-1. AC Power Supply, Model 3196.

- ☐ 1. Make sure that the power switch located on your side of the AC Power Supply is set to the O position.

Note: The AC Power Supply should already be installed in the Mobile Workstation.

- ☐ 2. Install the Lockout module into the Mobile Workstation.

Note: Each time you install a module in the Mobile Workstation, make sure that the fault switches located behind the module faceplate are set to the O position as shown in Figure C-2.




Figure C-2. Make sure that the fault switches are set to the O position.

- ☐ 3. Turn off the Lockout Module.

- ☐ 4. Connect the Lockout Module cables to the AC Power Supply module terminals, noting the phase sequence. See Figure C-3.



Figure C-3. Lockout Module connected to the AC Power Supply module.

Lockout/Tagout procedure (de-energizing procedure)

- ☐ 5. Turn off the Lockout Module.

- ☐ 6. Install the lockout hasp and the student padlocks and tags on the Lockout Module. Ask the instructor to install the lab padlock and tag as well. Refer to Figure C-4 for details.



Figure C-4. Installation of padlocks and hasps.

- ☐ 7. Check that the Lockout Module switch cannot be opened. With a voltmeter, verify that no voltage is present between the Lockout Module output terminals to confirm that the circuit is de-energized. You may now set up your circuit.

Energizing procedure

- ☐ 1. Interconnect the ground terminal (green) of all AC modules with the ground terminal of the Lockout Module.

Note: DC modules do not incorporate ground terminals.

- ☐ 2. Make sure the Security Guard is installed if you are using a motor.
- ☐ 3. Identify the modules with labels as described in the Module Identification section of this Appendix.

- ☐ 4. Once the connections have been made, ask for the instructor to check the circuit. When the circuit is correctly wired, notify all the people working around the Mobile Workstation that the system will be energized.
- ☐ 5. Remove the lockout hasp, padlocks and tags.
- ☐ 6. Turn on the AC Power Supply and Lockout Module, and return to your exercise.

Module identification

- ☐ 1. Once the setup is completed, identify all buttons, pilot lights, switches, etc. in accordance with the circuit schematic diagram. Place the magnetic labels on the module faceplates as shown in Figure C-5.




Figure C-5. Module identification.

Note: For storing purposes, arrange the magnetic labels in alphabetic order on the vertical surface of the Mobile Workstation as shown in Figure C-6.



Figure C-6. Store the magnetic labels on the vertical surface of the Mobile Workstation.

Coupling Motors

This procedure describes how to couple two motors on the Mobile Workstation.

Note: To facilitate electrical connections, the Brake Motor should be installed at your left.

- Fix the Brake Motor to the Mobile Workstation (See appendix E in the Basic Controls manual, part number 39163 if necessary).
- Remove the Inertia Wheel from the Brake Motor (when applicable).
- Slide a coupling half on the Brake Motor shaft taking care of aligning the coupling keyway with the key.
- Align the end of the coupling with the end of the shaft and tighten the set screw on the shaft key. See Figure D-1.




Figure D-1. Installation of a coupling half on a motor shaft.

- Install the insert in the coupling half.
- Slide a coupling half on the DC Motor taking care of aligning the coupling keyway with the key. Do not tighten the setscrew now.

- Position the DC Motor so the shafts of both motors are facing. Do not forget to insert the spacer plate between the motor base and the Mobile Workstation.
- Join the two coupling sections, allowing a 1.6 mm-gap (1/16 in) between the two halves sections, then tighten the setscrew.
- Align and fix the DC Motor to the Mobile Workstation surface using hexagonal head screws and knurled nuts.

Note: Misalignment will cause noise and vibration. Refer to Appendix E for basic information about alignment.

- Install the Safety Guard.

Note: Ask your instructor to check your setup.




Figure D-2. DC Motor coupled with the Brake Motor without Safety Guard.

Alignment

Flexible couplings

Flexible shaft couplings are used for joining shafts of equal or different diameters. A flexible jaw coupling is shown in Figure E-1.



Figure E-1. Flexible coupling.

Flexible couplings can usually compensate for slight errors in shaft alignment. Improper shaft alignment can lead to premature failure of couplings and bearings, and may cause excessive vibration.

Alignment

The two basic types of shaft misalignment are parallel and angular.

Parallel misalignment results when two shafts are parallel but not on the same plane, as shown in Figure E-2.



Figure E-2. Parallel misalignment.

Angular misalignment, also called axial misalignment, results when the shafts are at a different angle with the horizontal or vertical planes as shown in Figure E-3.



Figure E-3. Angular misalignment.

Both the vertical and horizontal planes must be checked to ensure a correct angular alignment.

Alignment methods

Depending on the required precision, many alignment methods may be used. One of the simplest methods (low precision method) is as follows:

- Lay a straightedge (supplied with the training system) as shown in Figure E-4 to check the alignment of the shafts in the horizontal plane.




Figure E-4. Alignment in the horizontal plane.

- The horizontal alignment is correct when the straightedge is in contact with the two coupling halves at any point. Alignment is adjusted in the horizontal plane by moving one of the motors to the right or left.

Note: Remove the labels on the coupling halves if necessary.

- Once the alignment in the horizontal plane is completed, lay the straightedge as shown in Figure E-5 to align the shafts in the vertical plane.




Figure E-5. Alignment in the vertical plane.

- Alignment is adjusted in the vertical plane by raising or lowering one of the motors with shims (supplied with the training system) as shown in Figure E-6.






Figure E-6. Insert shims to align the shafts in the vertical plane.

AC Drive – Error Codes and Parameter Numbers

ERROR CODES	
DISPLAY	CAUSE
E01	Inverter overcurrent in static operation
E02	Inverter overcurrent during deceleration
E03	Inverter overcurrent during acceleration
E05	Overload
E07	Overvoltage
E08	EEPROM fault
E09	Undervoltage
E11	Processor malfunction
E12	External fault message
E14	Ground fault
E15	Mains overvoltage
E21	Overtemperature
E35	Thermistor fault signal
E60	Communication fault

Monitor Mode (d□□□) / Basic Function Mode (F□□□)

Parameter No.	Name	Monitor or data range (Digital Operator)	Default setting	Changes during operation	Unit	Set value
d001	Output frequency monitor	0.0 to 400.0	—	—	Hz	
d002	Output current monitor	0.0 to 999.9	—	—	A	
d003	Rotation direction monitor	F: Forward o: Stop r: Reverse	—	—	—	
d004	PID feedback value monitor	0.00 to 99.99 100.0 to 999.9 1000. to 9999. (Enabled when the PID function is selected)	—	—	—	
d005	Multi-function input monitor	 <p>Example) Terminal S4, S2: ON Terminal S5, S3, S1: OFF</p>	—	—	—	
d006	Multi-function output monitor	 <p>Example) Terminal P1: ON Terminal MA: OFF</p>	—	—	—	
d007	Output frequency monitor (after conversion)	0.00 to 99.99 100.0 to 999.9 1000. to 9999. 1000 to 3996 (10000 to 39960) (Output frequency × Conversion factor of b086)	—	—	—	
d013	Output voltage monitor	0. to 600.	—	—	V	
d016	Total RUN Time	0. to 9999. 1000 to 9999 ┐100 to ┐999[h]	—	—	h	
d017	Power ON time monitor	0. to 9999. 1000 to 9999 ┐100 to ┐999[h]	—	—	h	
d018	Fin temperature monitor	0.0 to 200.0			°C	
d080	Fault frequency monitor	0. to 9999.	—	—	—	
d081	Fault monitor 1 (Latest)	Error code (condition of occurrence) → Output frequency [Hz] → Output current [A] → Internal DC voltage [V] → RUN time [h] → ON time [h]	—	—		
d082	Fault monitor 2					
d083	Fault monitor 3					

Parameter No.	Name	Monitor or data range (Digital Operator)	Default setting	Changes during operation	Unit	Set value
d102	DC voltage monitor	0.0 to 999.9	—	—	V	
d104	Electronic thermal monitor	0.0 to 100.0	—	—	%	
F001	Output frequency setting/monitor	Starting frequency to 1st or 2nd max. frequency	—	Yes	Hz	
F002	Acceleration time 1	0.01 to 99.99 100.0 to 999.9 1000. to 3000.	10.0	Yes	s	
F202	*2nd acceleration time 1	0.01 to 99.99 100.0 to 999.9 1000. to 3000.	10.0	Yes	s	
F003	Deceleration time 1	0.01 to 99.99 100.0 to 999.9 1000. to 3000.	10.0	Yes	s	
F203	*2nd deceleration time 1	0.01 to 99.99 100.0 to 999.9 1000. to 3000.	10.0	Yes	s	
F004	Operator rotation direction selection	00: Forward 01: Reverse	00	No	—	

* 2nd function is displayed when SET(08) is allocated to one of from C001 to C005.

Extended function mode

Parameter No.	Function name	Monitor or data range (Digital Operator)	Default setting	Changes during operation	Unit	Set value
Basic setting	A001	Frequency reference selection 00: Digital Operator (FREQ adjuster) 01: Terminal	00	No	—	
	A201	*2nd frequency reference selection 02: Digital Operator (F001) 03: ModBus communication 10: Frequency operation result	00	No	—	
	A002	RUN command selection 01: Terminal	02	No	—	
	A202	*2nd RUN command selection 02: Digital Operator 03: ModBus communication	02	No	—	
	A003	Base frequency 30. to Max. frequency [A004]	60.	No	Hz	
	A203	*2nd base frequency 30. to Max. frequency [A204]	60.			
	A004	Maximum frequency 30. to 400.	60.	No	Hz	
	A204	*2nd maximum frequency	60.			

* 2nd control is displayed when SET (08) is allocated to one of from C001 to C005.

Parameter No.	Function name	Monitor or data range (Digital Operator)	Default setting	Changes during operation	Unit	Set value
Analog input	A005	FV/FI selection 02: Switches between FV/FREQ adjuster via terminal AT 03: Switches between FI/FREQ adjuster via terminal AT 04: FV input only 05: FI input only	02	No	—	
	A011	FV start frequency	0.0 to Max. frequency	0.0	No	Hz
	A012	FV end frequency	0.0 to Max. frequency	0.0	No	Hz
	A013	FV start ratio	0. to 100.	0.	No	%
	A014	FV end ratio	0. to 100.	100.	No	%
	A015	FV start selection 00: External start frequency (A011 set value) 01: 0 Hz	01	No	—	
	A016	FV, FI sampling	1. to 17.	8.	No	—
Multi-step speed, Jogging	A020	Multi-step speed reference 0	0.0/Starting frequency to Max. frequency	6.0	Yes	Hz
	A220	*2nd multi-step speed reference 0	0.0/Starting frequency to 2nd max. frequency	6.0	Yes	Hz

* 2nd control is displayed when SET (08) is allocated to one of from C001 to C005.

Parameter No.	Function name	Monitor or data range (Digital Operator)	Default setting	Changes during operation	Unit	Set value
Multi-step speed, Jogging	A021	Multi-step speed reference 1	0.0	Yes	Hz	
	A022	Multi-step speed reference 2	0.0			
	A023	Multi-step speed reference 3	0.0			
	A024	Multi-step speed reference 4	0.0			
	A025	Multi-step speed reference 5	0.0			
	A026	Multi-step speed reference 6	0.0			
	A027	Multi-step speed reference 7	0.0			
	A028	Multi-step speed reference 8	0.0			
	A029	Multi-step speed reference 9	0.0			
	A030	Multi-step speed reference 10	0.0			
	A031	Multi-step speed reference 11	0.0			
	A032	Multi-step speed reference 12	0.0			
	A033	Multi-step speed reference 13	0.0			
	A034	Multi-step speed reference 14	0.0			
	A035	Multi-step speed reference 15	0.0			
	A038	Jogging frequency	0.00/Starting frequency to 9.99	6.00	Yes	Hz
	A039	Jogging stop selection	00: Free-run stop 01: Deceleration stop 02: DC injection braking stop	00	No	—

* 2nd control is displayed when SET (08) is allocated to one of from C001 to C005.

Parameter No.	Function name	Monitor or data range (Digital Operator)	Default setting	Changes during operation	Unit	Set value
Characteristics, Torque boost	A041	Torque boost selection 00: Manual torque boost only 01: Automatic (simple) torque boost	00	No	-	
	A241		00			
	A042	Manual torque boost voltage 0.0 to 20.0	5.0	Yes	%	
	A242		0.0			
	A043	Manual torque boost frequency 0.0 to 50.0	2.5	Yes	%	
	A243		0.0			
	A044	V/f characteristics selection 00: Constant torque characteristics (VC) 01: Reduced torque characteristics (VP 1.7th power) 06: Special reduced torque characteristics (Special VP)	00	No	-	
	A244		00			
	A045	Output voltage gain 20. to 100.	100.	Yes	%	
	A245		100.			
DC injection braking	A051	DC injection braking selection 00: Disabled 01: Enabled 02: Frequency control [A052 set value]	00	No	—	
	A052	DC injection braking frequency 0.0 to 60.0	0.5	No	Hz	
	A053	DC injection braking delay time 0.0 to 5.0	0.0	No	s	
	A054	DC injection braking power 0. to 100.	50	No	%	
	A055	DC injection braking time 0.0 to 60.0	0.5	No	s	
	A056	DC injection braking method selection 00: Edge operation 01: Level operation	01	No	—	

* 2nd control is displayed when SET (08) is allocated to one of from C001 to C005.

Parameter No.	Function name	Monitor or data range (Digital Operator)	Default setting	Changes during operation	Unit	Set value
Upper/Lower limit, Jump	A061	Frequency upper limit	0.0/Frequency lower limit to Max. frequency	0.0	No	Hz
	A261	*2nd frequency upper limit	0.0/Frequency lower limit to 2nd Max. frequency	0.0		
	A062	Frequency lower limit	0.0/Starting frequency to Frequency upper limit	0.0	No	Hz
	A262	*2nd frequency lower limit	0.0/Starting frequency to 2nd frequency upper limit	0.0		
	A063	Jump frequency 1	Jump frequency: 0.0 to 400.0 Jump frequency width: 0.0 to 10.0	0.0	No	Hz
	A064	Jump frequency width 1		0.5		
	A065	Jump frequency 2		0.0		
	A066	Jump frequency width 2		0.5		
	A067	Jump frequency 3		0.0		
	A068	Jump frequency width 3		0.5		
PID control	A071	PID selection	00: Disabled 01: Enabled	00	No	—
	A072	PID P gain	0.2 to 5.0	1.0	Yes	—
	A073	PID I gain	0.0 to 150.0	1.0	Yes	s
	A074	PID D gain	0.00 to 100.0	0.0	Yes	s
	A075	PID scale	0.01 to 99.99	1.00	No	Time
	A076	PID feedback selection	00: FI 01: FV 02: RS485 communication 10: Operation function output	00	No	—
	A077	Reverse PID function	00: OFF (Deviation = Target value - Feedback value) 01: ON (Deviation = Feedback value - Target value)	00	No	—
	A078	PID output limit function	0.00 to 100.0	0.0	No	%
AVR	A081	AVR selection	00: Always ON 01: Always OFF 02: OFF during deceleration	02	No	—
	A082	AVR voltage selection	200-V class: 200/215/220/230/240 400-V class: 380/400/415/440/460/480	200/ 400	No	V

* 2nd control is displayed when SET (08) is allocated to one of from C001 to C005.

Parameter No.	Function name	Monitor or data range (Digital Operator)	Default setting	Changes during operation	Unit	Set value
RUN mode, Acceleration/Deceleration functions	A085	RUN mode selection 00: Normal operation 01: Energy-saving operation	00	No	-	
	A086	Energy-saving response/ accuracy adjustment 0 to 100	50	No	%	
	A092	Acceleration time 2 0.01 to 99.99 100.0 to 999.9	15.00	Yes	s	
	A292	*2nd acceleration time 2 1000. to 3000.	15.00			
	A093	Deceleration time 2 0.01 to 99.99 100.0 to 999.9	15.00	Yes	s	
	A293	*2nd deceleration time 2 1000. to 3000.	15.00			
	A094	2-step acceleration/ deceleration selection 00: Switched via multi-function input 09 (2CH) 01: Switched by setting	00	No	—	
	A294	*2nd 2-step acceleration/ deceleration selection	00			
	A095	2-step acceleration frequency 0.0 to 400.0	0.0	No	Hz	
	A295	*2nd 2-step acceleration frequency	0.0			
	A096	2-step deceleration frequency 0.0 to 400.0	0.0	No	Hz	
	A296	*2nd 2-step deceleration frequency	0.0			
	A097	Acceleration pattern selection 00: Line 01: S-shape curve	00	No	—	
	A098	Deceleration pattern selection 00: Line 01: S-shape curve	00	No	—	

* 2nd control is displayed when SET (08) is allocated to one of from C001 to C005.

Parameter No.	Function name	Monitor or data range (Digital Operator)	Default setting	Changes during operation	Unit	Set value
External frequency adjustment	A101	FI start frequency	0.0 to 400.0	0.0	No	Hz
	A102	FI end frequency	0.0 to 400.0	0.0	No	Hz
	A103	FI start ratio	0. to 100.	0.	No	%
	A104	FI end ratio	0. to 100.	100.	No	%
	A105	FI start selection	00: Use FI start frequency [A101] 01: 0 Hz start	01	No	—
Operation frequency	A141	Operation frequency input A setting	00: Digital Operator (F001) 01: Digital Operator (FREQ adjuster) 02: Input FV	01	No	—
	A142	Operation frequency input B setting	03: Input FI 04: RS485 communication	02	No	—
	A143	Operator selection	00: Addition (A + B) 01: Subtraction (A - B) 02: Multiplication (A × B)	00	No	—
Frequency addition	A145	Frequency addition amount	0.0 to 400.0	0.0	Yes	Hz
	A146	Frequency addition direction	00: Adds A145 value to output frequency 01: Subtract A145 value from output frequency	00	No	—
VR adjustment	A151	VR start frequency	0.0 to 400.0	0.0	No	Hz
	A152	VR end frequency	0.0 to 400.0	0.0	No	Hz
	A153	VR start ratio	0. to 100.	0.	No	%
	A154	VR end ratio	0. to 100.	100.	No	%
	A155	VR start selection	00: Use VR start frequency [A151] 01: 0 Hz start	01	No	—

* 2nd control is displayed when SET (08) is allocated to one of from C001 to C005.

Parameter No.	Function name	Monitor or data range (Digital Operator)	Default setting	Changes during operation	Unit	Set value
Restart during momentary power interruption	b001	Retry selection 00: Alarm 01: 0 Hz start 02: Frequency matching start 03: Trip after frequency matching deceleration stop	00	No	—	
	b002	Allowable momentary power interruption time	1.0	No	s	
	b003	Retry wait time	1.0	No	s	
	b004	Momentary power interruption/ undervoltage trip during stop selection	00	No	—	
	b005	Momentary power interruption retry time selection	00	No	—	
	b011	Starting frequency at frequency pull-in restart	00	No	—	
Electronic thermal	b012	Electronic thermal level	Rated current	No	A	
	b212	*2nd electronic thermal level	Rated current			
	b013	Electronic thermal characteristics selection	00	No	—	
	b213	*2nd electronic thermal characteristics selection	00			

* 2nd control is displayed when SET (08) is allocated to one of from C001 to C005.

Parameter No.	Function name	Monitor or data range (Digital Operator)	Default setting	Changes during operation	Unit	Set value
Overload limit	b021	Overload limit selection	00: Disabled 01: Enabled in acceleration/constant speed operation	01	No	—
	b221	*2nd overload limit selection	02: Enabled in constant speed operation			
	b022	Overload limit level	0.1 × Rated current to 1.5 × Rated current	1.5 × Rated current	No	A
	b222	*2nd overload limit level				
	b023	Overload limit parameter	0.1 to 3000.0	1.0	No	s
	b223	*2nd overload limit parameter				
	b028	Overload limit source selection	00: b022, b222 set values 01: Input terminal FV	00	No	—
	b228	*2nd overload limit source selection				
Frequency pull-in	b029	Deceleration rate constant at frequency pull-in restart	0.1 to 3000.0	0.5	No	s
	b030	Frequency pull-in restart level	0.2 × Rated current to 2.0 × Rated current	Rated current	No	A
Lock	b031	Soft lock selection	00: Data other than b031 cannot be changed when terminal SFT is ON. 01: Data other than b031 and the specified frequency parameter cannot be changed when terminal SFT is ON. 02: Data other than b031 cannot be changed. 03: Data other than b031 and the specified frequency parameter cannot be changed. 10: Data other than parameters changeable during operation cannot be changed.	01	No	—

* 2nd control is displayed when SET (08) is allocated to one of from C001 to C005.

Parameter No.	Function name	Monitor or data range (Digital Operator)	Default setting	Changes during operation	Unit	Set value
Non-stop function at momentary power interruption	b050	Selection of non-stop function at momentary power interruption 00: Disabled 01: Enabled (Stop) 02: Enabled (Restart)	00	No		
	b051	Starting voltage of non-stop function at momentary power interruption 0.0 to 1000.	0.0	No	V	
	b052	Stop deceleration level of non-stop function at momentary power interruption 0.0 to 1000.	0.0	No	V	
	b053	Deceleration time of non-stop function at momentary power interruption 0.01 to 99.99 100.0 to 999.9 1000 to 3000	1.0	No	s	
	b054	Deceleration starting width of non-stop function at momentary power interruption 0.0 to 10.0	0.0	No	Hz	
Others	b055	Overvoltage protection proportional gain during deceleration 0.2 to 5.0	0.2	Yes	—	
	b056	Overvoltage protection integral time during deceleration 0.0 to 150.0	0.2	Yes	s	
	b080	AM adjustment 0. to 255. (Shared with C086 for AM offset adjustment)	100.	Yes	—	
	b082	Starting frequency 0.5 to 9.9	1.5	No	Hz	
	b083	Carrier frequency 2.0 to 12.0	3.0	No	kHz	
Initialization	b084	Initialization selection 00: Clears the trip monitor 01: Initializes data 02: Clears the trip monitor and initializes data	00	No	—	
	b085	Initialization parameter selection 00 * Do not change.	00	No	—	

* 2nd control is displayed when SET (08) is allocated to one of from C001 to C005.

Parameter No.	Function name	Monitor or data range (Digital Operator)	Default setting	Changes during operation	Unit	Set value
Others	b086	Frequency conversion coefficient	0.1 to 99.9	1.0	Yes	—
	b087	STOP key selection	00: Enabled 01: Disabled	00	No	—
	b088	Free-run stop selection	00: 0 Hz start 01: Frequency pull-in restart	00	No	—
	b089	Monitor display selection	01: Output frequency monitor 02: Output current monitor 03: Rotation direction monitor 04: PID feedback value monitor 05: Multi-function input monitor 06: Multi-function output monitor 07: Frequency conversion monitor	01	Yes	—
	b091	Stop selection	00: Deceleration → Stop 01: Free-run stop	00	No	—
	b092	Cooling fan control	00: Always ON 01: ON during RUN 02: Depends on the fin temperature	01	No	—
	b130	Overvoltage LAD stop function	00: Disabled 01: Enabled	00	No	—
	b131	Overvoltage LAD stop function level setting	200-V class: 330. to 395. 400-V class: 660. to 790.	380/ 760	Yes	V
	b133	Overvoltage protection function selection during deceleration	00: Disabled 01: Enabled	00	No	—
	b134	Overvoltage protection level setting during deceleration	200-V class: 330. to 395. 400-V class: 660. to 790.	380/ 760	No	V
	b140	Overcurrent suppression function	00: Disabled 01: Enabled	01	No	—
	b150	Automatic carrier reduction	00: Disabled 01: Enabled	00	No	—
	b151	Ready function selection	00: Disabled 01: Enabled	00	No	—

* 2nd control is displayed when SET (08) is allocated to one of from C001 to C005.

Parameter No.	Function name	Monitor or data range (Digital Operator)	Default setting	Changes during operation	Unit	Set value
Multi-function input terminals	C001	Multi-function input 1 selection	00	No	—	
	C201	*2nd multi-function input 1 selection	00			
	C002	Multi-function input 2 selection	01			
	C202	*2nd multi-function input 2 selection	01			
	C003	Multi-function input 3 selection	18			
	C203	*2nd multi-function input 3 selection	18			
	C004	Multi-function input 4 selection	12			
	C204	*2nd multi-function input 4 selection	12			
	C005	Multi-function input 5 selection	02			
	C205	*2nd multi-function input 5 selection	02			
	C011	Multi-function input 1 operation selection	00	No	—	
	C012	Multi-function input 2 operation selection	00			
	C013	Multi-function input 3 operation selection	00			
	C014	Multi-function input 4 operation selection	00			
	C015	Multi-function input 5 operation selection	00			

* 2nd control is displayed when SET (08) is allocated to one of from C001 to C005.

Parameter No.	Function name	Monitor or data range (Digital Operator)	Default setting	Changes during operation	Unit	Set value
Multi-function output setting	C021	Multi-function output terminal P1 selection 00: RUN (signal during RUN) 01: FA1 (constant speed arrival signal) 02: FA2 (over set frequency arrival signal) 03: OL (overload warning) 04: OD (excessive PID deviation) 05: AL (alarm output)	00	No	—	
	C026	Relay output (MA, MB) function selection 06: Dc (disconnection detection) 07: FBV (PID FB status output) 08: NDc (network error) 09: LOG(logic operation output) 10: ODc (Do not use.) 43: LOC (light load detection signal)	05			
	C028	AM selection 00: Output frequency 01: Output current	00	No	—	
	C031	Multi-function output terminal P1 contact selection 00: NO contact at MA; NC contact at MB	00	No	—	
	C036	Relay output (MA, MB) contact selection 01: NC contact at MA; NO contact at MB	01			
	C038	Light load signal output mode 00: Enabled during acceleration/deceleration/constant speed 01: Enabled only during constant speed	01	No	—	
	C039	Light load detection level 0.0 to 2.0 × Rated current (0.0 setting: Function disable)	Rated current	No	—	
Level output status setting	C041	Overload warning level 0.0: Does not operate	Rated current	No	A	
	C241	*2nd overload warning level 0.1 × Rated current to 2.0 × Rated current	Rated current			
	C042	Arrival frequency during acceleration 0.0 to 400.0	0.0	No	Hz	
	C043	Arrival frequency during deceleration 0.0 to 400.0	0.0	No	Hz	
	C044	PID deviation excessive level 0.0 to 100.0	3.0	No	%	
	C052	PID FB upper limit 0.0 to 100.0	100	No	%	
	C053	PID FB lower limit	0.0			

* 2nd control is displayed when SET (08) is allocated to one of from C001 to C005.

Parameter No.	Function name	Monitor or data range (Digital Operator)	Default setting	Changes during operation	Unit	Set value
Communication function adjustment	C070	Operator/ModBus selection 02: Digital Operator 03: ModBus	02	No	—	
	C071	Communication speed selection (Baud rate selection) 04: 4800 bps 05: 9600 bps 06: 19200 bps	04	No	—	
	C072	Communication station No. selection 1. to 32.	1.	No	—	
	C074	Communication parity selection 00: No parity 01: Even 02: Odd	00	No	—	
	C075	Communication stop bit selection 1: 1-bit 2: 2-bit	1	No	—	
	C076	Communication error selection 00: Trip 01: Trip after deceleration stop 02: Ignore 03: Free run 04: Deceleration stop	02	No	—	
	C077	Communication error timeout 0.00 to 99.99	0.00	No	s	
	C078	Communication wait time 0. to 1000.	0.	No	ms	
Various adjustment	C081	FV adjustment 0.0 to 200.0	100.0	Yes	%	
	C082	FI adjustment 0.0 to 200.0	100.0	Yes	%	

* 2nd control is displayed when SET (08) is allocated to one of from C001 to C005.

Parameter No.	Function name	Monitor or data range (Digital Operator)	Default setting	Changes during operation	Unit	Set value
Others	C086	AM offset adjustment	0.0 to 10.0	0.0	Yes	V
	C091	Not used	Use "00". *Do not change.	00	—	—
	C101	UP/DWN selection	00: Do not store the frequency data 01: Store the frequency data	00	No	—
	C102	Reset selection	00: Trip reset at power-on 01: Trip reset when the power is OFF 02: Enabled only during trip (Reset when the power is ON.)	00	No	—
	C141	Logic operation function A input	00: RUN (signal during RUN) 01: FA1 (constant speed arrival signal) 02: FA2 (over set frequency arrival signal) 03: OL (overload warning) 04: OD (excessive PID deviation) 05: AL (alarm output)	00	No	—
	C142	Logic operation function B input	06: Dc (disconnection detected) 07: FBV (PID FB status output) 08: NDc (network error) 10: ODc (Do not use.) 43: LOC (light load detection signal)	01	No	—
	C143	Logic operator selection	00: AND 01: OR 02: XOR	00	No	—
	C144	Output terminal P1 ON delay	0.0 to 100.0	0.0	No	s
	C145	Output terminal P1 OFF delay	0.0 to 100.0	0.0	No	s
	C148	Relay output ON delay	0.0 to 100.0	0.0	No	s
	C149	Relay output OFF delay	0.0 to 100.0	0.0	No	s
Control parameter	H003	Motor capacity selection	200-V class 0.2/0.4/0.75/1.5/2.2/3.7/5.5/7.5	Factory default	No	kW
	H203	*2nd motor capacity selection	400-V class 0.4/0.75/1.5/2.2/3.7/5.5/7.5	Factory default		
	H004	Motor pole number selection	2 4 6 8	4	No	Pole
	H204	*2nd motor pole number selection		4		
	H006	Stabilization parameter	0. to 255.	100	Yes	%
	H206	*2nd stabilization parameter		100	Yes	%

* 2nd control is displayed when SET (08) is allocated to one of from C001 to C005.

DC Motor Characteristics

The characteristics of the DC Motor are:

RATINGS	120 V	220 V	240 V
Power rating (hp)	1/3	1/3	
Full-load current (A)	3.6	1.8	
Armature DC volts	90	180	
Enclosure type	TEFC		
Duty rating	CONT.		
Maximum ambient temperature [°C (°F)]	40 (104)		
Rotation speed (r/min)	1750		
Torque	1.52 n•m (13.5 lb•in)		
Insulation class	F		